


SPM to PERMANENT MAGNET MOTOR NO REVERSE

PART NO. A



NOTES:

- * FUSES REQUIRED FOR ALL INSTALLATIONS
- * DIODE REQUIRED ACROSS COILS / RELAYS
- * PRE-CHARGE RESISTOR REQUIRED
- > ASSUMES FOOTSWITCH IS OPEN WHEN THROTTLE DFF
- > ALLTRAX RESERVES THE RIGHT TO CHANGE DOCUMENTATION
- > WITHOUT NOTICE AND WARRANTY AS TO THE ACCURACY, SUFFICIENCY, OR SUITABILITY OF ANY TECHNICAL OR OTHER INFORMATION PROVIDED
- > SEE OPERATORS MANUAL FOR MORE INFORMATION

DO NOT SCALE DRAWING

REVISIONS			
REV.	ECO.	DATE	APVD

DWG SCALE: 1:1	DRAWN/RICHARD CSUK 11/15/10
ENG/DAMON CROCKETT 11/15/10	

PROPRIETARY
THIS TECHNICAL DATA IS PROPRIETARY
AND IS RELEASED, OR DISCLOSED
IN WHOLE OR IN PART WITHOUT WRITTEN
PERMISSION OF ALLTRAX INC.

ALLTRAX 1111 Cheney Creek Rd.
Grants Pass, OR 97527
PHONE:(541) 476-3565

TITLE
SPM- PERMANENT MAGNET W/O REVERSE
Wiring Diagram

SIZE DOCUMENT NO.

REV. A

FILE:300110-006-A-IMP-SPM-PM-MAGNET-W/O-REVERSE-IMP-0A
SHEET 1 OF 1