

WITH REVERSE

Wiring diagram for the F&R switch and KSI switches. The F&R switch is labeled "F&R SWITCH ON-OFF-ON". It is connected to a "RED" wire. The KSI switch is labeled "KSI". It is connected to a "RED" wire. The diagram shows the internal wiring of the switches and their connection to the power source.



3	
FUSE	CONTROLLER RATING
100A	100A
150A	150A
200A	200A
250A	250A
300A	300A
350A	350A
400A	400A
450A	450A
500A	500A
550A	550A
600A	600A
650A	650A
700A	700A
750A	750A
800A	800A
850A	850A
900A	900A
950A	950A
1000A	1000A

DIODE RATING	CONTACTOR RATING
1N4001	DEM
1N5408	200A
MR754	400A

- FLUSES REQUIRED FOR ALL INSTALLATIONS
- DIODE REQUIRED ACROSS COILS / RELAYS
- TOW/RUN SWITCH PREVENTS REGEN WHILE TOWING
- ASSUMES FLODSWITCH IS OPEN WHEN THROTTLE OFF
- ALLTRAX RESERVES THE RIGHT TO CHANGE DOCUMENTATION WITHOUT NOTICE
- ALLTRAX MAKES NO WARRANTY AS TO THE ACCURACY, SUFFICIENCY, OR SUITABILITY OF ANY TECHNICAL OR OTHER INFORMATION PROVIDED
- SEE OPERATORS MANUAL FOR MORE INFORMATION

ALLTRAX
1111 Cheney Creek Rd.
Grants Pass, OR 97527
PHONE: (541) 476-3565

11/11/2023

TITLE		
SR to Generic Series Reverse Wiring Diagram		
SIZE	DOCUMENT NO.	REV.